Evaluation of Surrogate Methods for Real-Time PM_{2.5} AQI Reporting By AIRNow


Predicting the 'Mid-24' Using Available Hourly Data

Nancy McMillan
Battelle
February 24, 2004



Surrogate Methods: Why do we need them?

Hourly Measurements vs. 24-hour Midnight-Midnight Standard



AQI Reported on AIRNow website using



Environment and Energy

Surrogate Methods

Four Methods Evaluated for Estimating the Mid-24

- EPA provided
 - Four surrogate methods,
 - Four specific evaluation criteria, and
 - Four MSAs in which to evaluate methods.
- Battelle developed
 - Metrics to measure how well methods performed relative to evaluation criteria,
 - Acquired PM data from each MSA, and
 - Applied each metrics to each method in each MSA.
- EPA reviewed results and selected method that best predicts the 'Mid-24'.

Four Surrogate Methods

Conroy Method

- Average of the 12-hour average and an adjusted 4-hour average
- Adjusted 4-hour average is less than actual 4-hour average when PM_{2.5} is high (>30 ìg/m³) and change is slow

Knowles Method

- Examines the trend in the 1-hour PM_{2.5} concentration and the current 3-hour average compared to the 12-hour and 24-hour averages. It then applies one of two weighting schemes to estimate the Mid-24
- Average of the
 - 12-hour average and 70% of the 3-hour average (when very short term change is in the opposite direction of short term change)
 - 12-hour average and the 3-hour average (very short term change and short term change are consistent)

Four Surrogate Methods (cont)

Weinstock Method

- Uses one of three averaging periods to estimate the Mid-24
 - 6-hour (rapid change),
 - 12-hour (moderate change), and
 - 24-hours (slow change)
- Which averaging period should be used is determined based on the value of the ratio of the 6-hour average to the 24-hour average (6hour/24-hour)

Rizzo Method

Use the 8-hour average to estimate the Mid-24

Four Criteria

Criterion 1:

 Surrogate method should work for all regions and should be operable at all data management centers.

Criterion 2:

Surrogate method should be within 80% of the value of the Mid-24 80% of the time.

Criterion 3:

 Surrogate method should identify spikes in PM2.5 rapidly (within 2 – 3 hours) and recover rapidly (within 2 – 3 hours) when concentrations fall.

Criterion 4:

 Surrogate method should not be overly sensitive to outliers caused by local sources.

Criterion 1: Surrogate method should work for all regions and should be operable at all data management centers.

- Represent each of the following regions of the U.S.:
 - southern states
 - western states
 - northeastern states
 - midwestern states
- Evaluated against hourly PM_{2.5} measurements observed in four cities
 - Atlanta, GA
 - Bakersfield, CA
 - Baltimore, MD
 - Chicago, IL
- Data from April 2002-April 2003 used

Criterion 2: Surrogate method should be within 80% of the value of the Mid-24 80% of the time.

 Determined what percentage of the time each method's hourly value was within the interval
 (Mid-24 - 0.20*Mid-24, Mid-24 + 0.20*Mid-24)


 Percentages were so low as to warrant relaxing the above interval

(Mid-24 - 0.30*Mid-24, Mid-24 + 0.30*Mid-24)

Also determined percentage of time each method within similar intervals based on hourly readings

Criterion 3: Surrogate method should identify spikes in $PM_{2.5}$ rapidly (within 2 – 3 hours) and recover rapidly (within 2 – 3 hours) when concentrations fall.

- Define two types of events:
 - Moderate AQI Events
 - periods when the Mid-24 exceeds the Moderate threshold
 - USG (Unhealthy for Sensitive Groups) AQI Events
 - periods when the Mid-24 exceeds the USG AQI threshold



- Define two metrics:
 - Percentage of time method is false negative or false positive
 - Average lag between the time the Mid-24 begins (ends) a Moderate or USG AQI Event and the time a surrogate method begins (ends) the corresponding event
- Metrics applied to Mid-24 and hourly data

Criterion 4: Surrogate method should not be overly sensitive to outliers caused by local sources.


- Count 'Extra Events'
 - Determined number of times each method evidenced a Moderate (USG) AQI Event that did not correspond to a value of the Mid-24 that was above the Moderate (USG) level within six hours

Did not compare the surrogate methods to the hourly PM_{2.5} measurements using this metric

Atlanta

One CAMMS mass pressure drop monitor (id: 13-089-0002-88101-2)


Data characterized by highly variable, but not very large hourly readings



Bakersfield

Two hourly Beta attenuation monitors (ids: 06-029-0014-88101-3 and 06-029-0014-88101-4)


Data characterized by highly variable and often very large PM2.5 values



Baltimore

One hourly TEOM
Gravimetric 50 deg C
monitor (id: 24-520-0040-88101-2)


Data generally less variable than the data for Atlanta and Bakersfield



Chicago

Three hourly Beta attenuation monitors (ids: 17-031-0076-88101-3 17-031-0022-88101-3 and 17-031-0057-88101-3)


Data less variable than the data for Atlanta and Bakersfield, more USG events than any city other than Bakersfield



Results: Criteria 2

Conroy's method outperforms the other three methods with respect to Criterion 2. If performance relative to the hourly data is considered paramount, the Knowle method may be a good alternative.

Percentages of time surrogate methods reproduce the hourly and Mid-24, averaged over all cities.




Results: Criteria 3

Error Rate

The Conroy method outperforms the other methods when comparing to the Mid-24. The Weinstock method also performs well. The **Knowle and Conroy** methods perform equally well with respect to the hourly data.


Percentage of time surrogate methods indicate false positive and negative Moderate and USG AQI events, averaged over all cities (false positives and negatives are summed for each method).



Event lag (hourly) – Missed events

The Knowle method captures hourly Moderate AQI Events best. The Conroy, Rizzo, and Knowle methods perform comparably in terms of capturing USG AQI Events.


Percentage of missed Events according to the hourly PM2.5, averaged over all cities



Event lag (hourly)

The Knowle and Conroy methods demonstrate comparable USG AQI Event departure lags when comparing to the hourly data. The Knowle method demonstrates the shortest lag in identifying Moderate AQI Events, followed closely by the Conroy method.


Average onset and departure lag for USG events according to the hourly PM2.5, averaged over all cities



Event lag (Mid-24) – Missed events

The Knowle method captures more Mid-24 Moderate and USG AOI Events than any of the other methods. The Conroy method outperforms the Rizzo and Weinstock methods with respect to this metric, but misses about 5% more Moderate and USG AQI events than the Knowle method. Battel e


Percentage of missed Events according to the Mid-24, averaged over all cities.



Event lag (Mid-24)

Mid-24 Moderate and USG onset lags are comparable across all four methods. The Knowle method is the best performer in terms of Mid-24 Moderate and USG departure lags.


Average onset and departure lag for USG events according to the Mid-24, averaged over all cities



Results: Criteria 4

Because the Mid-24 is a 24-hour average, it may occasionally "average out" successive peaks in the hourly data. Thus, any method catching all of the actual peaks in this scenario could be penalized for creating extra events relative to the Mid-24.

Sum across cities of extra Moderate and USG AQI events



Summary of Best Performing Surrogate Methods with Respect to Each Evaluation Criterion

| According to: | Within 70%/80% | Recovers Quickly | Not Overly- Sensitive | Generalizable/Operable |
|---------------|----------------|---------------------|--------------------------|------------------------|
| Hourly | Knowle | Knowle | N/A | All |
| Mid - 24 | Conroy | Knowle Conroy | Conroy Weinstock | All |